



Commutateur étage 4 (HP 2530G-48G)



Table des matières

I – Configuration.....	3
II – Commandes.....	4



I – Configuration

VLAN :

Vlan 20 : reseausys 10.0.20.0 /24

Vlan 22 : Gestion 10.0.22.0 /24

Vlan 50 : Administration 10.0.50.0 /24

IP: 10.0.22.254

Port 1 : Trunk

Ports 2 – 18 : vlan gestion

Ports 19-36 : vlan reseausys

Ports 37-48 : vlan administration

SSH activé

Utilisateurs:

manager admini

operator admini



II – Commandes

Création vlan :

VLAN 20 : reseausys
<pre>#conf t #vlan 20 #name «reseausys» #ip address 10.0.20.0 255.255.255.0</pre>
VLAN 22 : Gestion
<pre>#conf t #vlan 22 #name «Gestion» #ip address 10.0.22.0 255.255.255.0</pre>
VLAN 50 : Administration
<pre>#conf t #vlan 50 #name «Administration» #ip address 10.0.50.0 255.255.255.0</pre>



Fiche de procédure

Adresse ip commutateur :

Adresse IP
Menu > Switch Configuration > IP configuration IP Address : 10.0.22.254 Subnet Mask : 255.255.255.0

Connexion utilisateurs :

Mots de passes
#Conf t #password manager #admini #password operator #admini

SSH :

SSH
Interface web > Service SSH Enable SSH